

## EPSON Stylus Photo 1290 Specifications

<b>Printer Type</b> Printing Method  Nozzle Configuration  Print Direction	On-demand ink jet (piezoelectric)  48 nozzles (Black) 48 nozzles x5 (Cyan, Light Cyan, Magenta, Light Magenta, Yellow)  Bi-directional with logic seeking
<b>Print Speed</b> Photo A4 (8 x 10 ")  Black Text (Memo) A4  Colour Text (Memo) A4  Text & Colour Graphics	220 sec. per photo* <sup>♦1</sup>  Approx. 9.4 PPM (Economy) <sup>♦2</sup>  Approx. 9.0 PPM (Economy) <sup>♦3</sup>  Approx. 2.0 PPM (Normal) <sup>♦4</sup>
<b>Resolution</b>	Max. 2880dpi x 720dpi (with Variable-Sized Droplet Technology)
<b>Paper Handling</b> Paper Sizes	A3+, A3, A4, A5, Envelopes (No.10, DL, C6, 132 x 220 mm), Index Card (A6, 5 x 8", 8 x 10"), B4, B5, A6 Index, Roll Paper (329 mm x 10 m, 210 mm x 10 m, 127 mm x 8 m, 100 mm x 8 m, 89 mm x 7 m)**
<b>Interface</b>	Parallel & USB <sup>†</sup> interface
<b>Ink Cartridges</b> Black Ink Cartridge (T007) Type Colour Print Capacity  Black Ink Cartridge (T010) Type Colour Print Capacity  Colour Ink Cartridge (T009) Type Colours  Print Capacity	Exclusive cartridge Black 540 pp, 3.5% at 360dpi (370 pp, 5% in calculation)  Exclusive cartridge Black 270 pp, 3.5% at 360dpi  Exclusive cartridge Cyan, Light Cyan, Magenta, Light Magenta, Yellow 330 pp, 5% each YMCLmLc (25% total) in calculation
<b>Printer Software on CD-ROM</b> Printer Drivers   Online Guide	Microsoft® Windows® 95/98/2000/ME Microsoft® Windows® NT® 4.0 Macintosh  Yes

## Consumables

### Special Media

EPSON PHOTO QUALITY GLOSSY FILM (A4)	S041071
EPSON PHOTO QUALITY GLOSSY FILM (A3)	S041073
EPSON PHOTO QUALITY GLOSSY FILM (A3+)	S041074
EPSON PHOTO QUALITY INK JET PAPER (A4)	S041061
EPSON PHOTO QUALITY INK JET PAPER (A3)	S041068
EPSON PHOTO QUALITY INK JET PAPER (A3+)	S041069
EPSON INK JET TRANSPARENCIES (A4)	S041063
EPSON PHOTO QUALITY INK JET CARD (5" x 8")	S041121
EPSON PHOTO QUALITY INK JET CARD (8" x 10")	S041122
EPSON PHOTO QUALITY INK JET CARD (A6)	S041054
EPSON PHOTO PAPER (A4)	S041140
EPSON PHOTO PAPER (A3)	S041142
EPSON PHOTO PAPER (A3+)	S041143
EPSON PHOTO PAPER (329mm x 10m)	S041233
EPSON PHOTO PAPER (210mm x 10m)	S041280
EPSON PHOTO PAPER (100mm x 8m)	S041279
EPSON PHOTO PAPER (89mm x 7m)	S041281
EPSON PANORAMIC PHOTO PAPER	S041145
EPSON INK JET BACK LIGHT FILM (A3)	S041131
EPSON PHOTO QUALITY SELF ADHESIVE SHEET (A4)	S041106
EPSON IRON-ON COOL PEEL TRANSFER PAPER (A4)	S041154
EPSON MATTE PAPER — HEAVYWEIGHT (A4)	S041259
EPSON MATTE PAPER — HEAVYWEIGHT (A3)	S041262
EPSON MATTE PAPER — HEAVYWEIGHT (A3+)	S041265
EPSON PREMIUM GLOSSY PHOTO PAPER (A4)	S041297
EPSON PREMIUM GLOSSY PHOTO PAPER (A3)	S041288
EPSON PREMIUM GLOSSY PHOTO PAPER (A3+)	S041289
EPSON PREMIUM GLOSSY PHOTO PAPER (89mm x 7m)	S041301
EPSON PREMIUM GLOSSY PHOTO PAPER (100mm x 8m)	S041302
EPSON PREMIUM GLOSSY PHOTO PAPER (127mm x 8m)	S041474

### OPTIONS

EPSON StylusRIP	C842622
EPSON Net10/100 BaseTX EXT. Print Server	C823784

\* When printed on EPSON Photo Paper.

\*\* Roll paper holder (bundled) is required.

† To use the USB port, your PC must conform to PC98 specifications, and have Windows preinstalled. Consult the documentation provided with your PC for further information about USB connectivity. Note also that printing errors may occur if non-standard cables or more than two hub connections are used.

### Print Speed Data Printout Patterns

The thumbnail images below show the printout patterns used to determine print speed specifications.



♦1  
Photo A4  
Photo A3  
(Photo courtesy  
of ISO/JIS-SCID.  
Reprinted by  
Permission.)



♦2  
Black Text  
(MEMO) A4



♦3  
Colour Text  
(MEMO) A4



♦4  
Text & Colour Graphics